

T&J ELECTRIC (SINGAPORE) PTE LTD

Company Registration No: 200205797Z 10 Ubi Crescent, #02-24, Ubi Techpark, Singapore 408564 Telephone: +65 6547-4333 Fax: +65 6547-4666


Date: April 13, 2010

Subject: Product Information for TV / FM / SAT Triplexer

Product Features

• Three output connectors: TV, Radio and Sat.

- Comprise with two parts:
 - a. Center Plate
 - b. Insert
- Two different type of Insert.
 - a. K8553-MI end type SMATV insert.



- Cover plate
 - a. K8553-FR center plate for Radiance range.
 - b. HB8553-FR center plate for Dazzle range.
- Zinc die cast housing.
- All port connector 75 ohm.
- Connector:

a. TV: IEC 169-2 (m)b. Radio: IEC 169-2 (f)

c. Sat: F(f)



Complete Product



T&J ELECTRIC (SINGAPORE) PTE LTD

Company Registration No: 200205797Z 10 Ubi Crescent, #02-24, Ubi Techpark, Singapore 408564 Telephone: +65 6547-4333 Fax: +65 6547-4666

Technical Specification of insert

Insert Type		K8553-MI	K8563-MI
Frequency Range (MHz)	IN – OUT	5 - 2250	
	IN - TV	5 - 74 / 120 - 860	
	IN - FM	88 - 108	
	IN - SAT	950 – 2250	
Tap Loss (dB)	IN - OUT	-	4.0 - 7.0
	IN - TV	1.5 - 2.5	6.0 - 10.0
	IN - FM	2.0	7.0 - 9.0
	IN - SAT	2.0 - 3.0	7.0 - 11.0
Connector	IN / OUT	Coaxial	
	TV	IEC – Male	
	FM	IEC – Female	
	SAT	F Type Female	
RFI Shielding (dB)		100	
Isolation (dB)		> 20	

Order Code

Insert Type	Description
K8553-MI	SMATV insert (end type)
K8563-MI	SMATV insert (loop type)
K8553-FR-xxx	Cover plate for Radiance range.
	xx - represent the color code
HB8553-FR	Cover plate for Dazzle range

T&J ELECTRIC (SINGAPORE) PTE LTD

Company Registration No: 200205797Z 10 Ubi Crescent, #02-24, Ubi Techpark, Singapore 408564 Telephone: +65 6547-4333 Fax: +65 6547-4666

Installation Notes

K8553-MI

Coaxial cable is connected on the right hand side which is indicated with a "IN" Arrow on the cable clamp.


The screw near the FM outlet is used to fasten the coaxial cable core.

K8563-MI

"IN" Coaxial cable is connected on the right hand side which is indicated with a "IN" Arrow on the cable clamp.

"OUT" Coaxial Cable is connected on the left hand side which is indicated with a "OUT" Arrow on the cable clamp.

The screw near "TV" and "FM" outlet is used to fasten the coaxial cable core respectively.



Installation with K8553-MI inserts